























HVR Web Interface

Home

Network Setup

Flash Setup

Sys Maintenance

Sys Information

Set-Password

HVR Interface

The HVR Solid State Recorder utilizes proven aircraft technology to provide storage capacity exceeding 12 hours of radar, sensor, and audio data. The final recording medium is stored in a protective capsule within the HVR that is fitted with an Underwater Locator Beacon (ULB) to aid in locating the recorder in the event of a catastrophic incident. The HVR will be located in the vicinity of the bridge on the external deck area of a vessel so as to maximize the probability of its

The HVR is designed to meet or exceed the following IEC test specifications:

- Shock 11 millisecond duration or 50g
- Penetration 3m, 250 kg drop test

survival and recovery following an incident.

- Fire 1100 C for 1 hour / 260 C for 10 hours
- Deep Sea Immersion 30 days at 6,000m of depth

F16.12

	Login Screen		
Home	i		
Network Setup	}	Administra	or Access
Flash Setup	1	Enter	F ************************************
Sys Maintenance		Password:	
Sys Information			Submit
Set Password			
(TIVR Interface			
4800647			
		_	
	F	-16,13	
07050		•	
Environment Environment Environment			

(Network Setup

Home	Parameter	Current Value	New Value
Network Setup	HVR IP Address	192.168.0.2	
Flash Setup	HVR Subnet Mask	255.255.255.0	
	Default Gateway IP	192.158.0.1	
Sys Maintenance	Session Time-out (Seconds)	300 seconds	
Sys Information)			, L

Submit

Set Password

HVR Interface

F16,14

IIVR Memory Partition Configuration						
Jotal Devices in Crash Module 96						
			0 1			
Update Device Allocations and Stream Names						
Position	Devices	Drivices	Stream Name	Stream Name		
0	16		Stream_0			
1	16		Stream_1			
2	16		Stream_2			
3	16		Stream_3			
1	16		Stream_4			
5	16		Stream_5			
6	0		Stream_6			
7	0		Sucam_7			
8	0		Stream_8			
9	0		Stream_9			
	Dutal Deckir Number of Courrent's 1 Position 0 1 2 3 4 5 6 7 8	Dotal Devices in Crash Number of Byers Per De Courrently Leastsqueed De Courrently Leastsqueed De Position Devices	Data Devices in Crash Module Number of Byers Per Devices Coursel's Hossigned Devices Update Devices Drvices 1	Dotal Devices in Crash Module		

Submit Changes

F16.15